

INSTRUCTION MANUAL

WOOD STOVE FALCONWOOD

8618600



Fire prevention

Choose the barbecue site to stay away from flammable materials, adjacent to the water source, with a bucket container ready water next to the oven in case, once there is any hidden danger, can be put out in time water. After the activity to check whether there is any fire, fire completely extinguished before leaving.

Anti-scald

Don't play around in the barbecue area when you have an outdoor barbecue. Those with children, please keep an eye on the children. Oven itself temperature is very high, do not touch, prepare a few anti-scald medicine is also a very good preventive measure.

Indoor tent heating


Keep vents to avoid carbon monoxide poisoning, and keep the stove and tent away from flammable materials.

Gloves, fire hooks

Always wear gloves when using the stove, and always use a fire hook when opening the top cover and middle cover to prevent scald.

Usage

1. Press the marble on the furnace foot with your finger, and pull the furnace foot so that the marble on the furnace foot is placed on the second limit hole.
2. Open the furnace door, take out the stop plate and chimney, and install them on the furnace body respectively.
3. Put a little dry material, put in the ignition cotton (alcohol) can be lit.
4. After lighting the fire, close the door of the furnace and open the Grate inlet (9) to calculate the air inlet.
5. If cooking soup, remove the top cover and plate the appropriate pan.
6. If you want Teppanyaki and barbecue, remove the middle cover plate and put it on the Teppanyaki or barbecue net.



1. The furnace
2. Carrying plate
3. Check baffle
4. The chimney
5. Oven door
6. Peepsight
7. The furnace foot
8. The cover plate
9. Grate inlet
10. Grate (bottom air) inlet
11. Secondary and tertiary combustion of air intake products